

DM10 Midi Note Map

Note Number	Trigger	Sound
25	Ride R	Ride Edge
26	Ride Switch	Ride Choke
27		
28	Perc. 4 H	Conga Hi Open
29	Perc. 4 R	Conga Low Open
30	Hi-Hat Pedal	Hi-Hat Heel Splash
31	Hi-Hat R	Hi-Hat Shank Closed
32	Hi-Hat R	Hi-Hat Shank Open/Variable
33	Perc. 1 R	Bongo Hi
34	Crash Switch	Crash Choke
35	Bass Drum R	Bass Drum 2
36	Bass Drum H	Bass Drum
37		Cross Stick
38	Snare Drum H	Snare Drum
39		Elec. Clap
40	Snare Drum R	Snare Rim Shot
41	Tom 3 R	Random Conga Hi
42	Hi-Hat H	Hi-Hat Bow Closed
43	Tom 3 H	14" Tom
44	Hi-Hat Pedal	Hi-Hat Pedal Chick
45	Tom 2 H	12" Tom
46	Hi-Hat H	Hi-Hat Bow Open/Variable
47	Tom 1 H	10" Tom
48	Tom 2 R	Cowbell 3
49	Crash	Crash
50	Tom 1 R	Tambourine Tight
51	Ride H	Ride Bow
52		China
53	Ride B	Ride Bell
54		Tambourine Open
55		Splash
56		Cowbell 2
57		Crash* Tied to Crash input on mixer... intended as Crash R?
58		Vibraslap
59	Perc. 1 H	Ride 2
60	Perc. 2 H	Crash 2
61	Perc. 2 R	Bongo Low
62		Conga Hi Mute
63	Perc. 3 H	16" Tom
64	Perc. 3 R	Splash
65		Timbale Hi
66		Timbale Low
67		Agogo Hi
68		Agogo Low
69		Cabasa
70		Maracas
71		Whistle Short
72		Whistle Long
73		Guiro Short
74		Guiro Long
75		Claves
76		Temple Block
77		Wood Block
78		Cuica Down
79		Cuica Up
80		Triangle Muted
81		Triangle Open
82		Djembe
83		Doumbek
84		Finger Cymbals
85		Flexatone
86		Gong
87		Pandiero Mute
88		Pandiero Open
89		Orchestral Crash
90		Reco Reco
91		Timpani